




# ASML


## ASML Holistic Lithography Open Your Window to Shrink

Bert Koek, SVP litho applications

Semicon West, July 14, 2009




# Shrink is good...except when it's not



- Shrink reduces manufacturing cost and improves device performance
- **However**, shrink results in smaller process windows which compromise yield by restricting production tolerances


# Holistic lithography provides a window to shrink




- Holistic lithography is the intelligent integration of computational lithography, wafer lithography and process control.
  - Before manufacturing, holistic lithography optimizes the process window at lower R&D cost
  - During manufacturing, holistic lithography keeps the process in the “sweet spot” of the window.



# Optimized process window




# Actual scanner data enables better process window





# Faster time-to-money



# Faster time-to-money




Design verification is known much earlier:

- reducing design proofs
- reducing R&D cost
- reducing time to volume ramp-up
- higher yield at ramp to volume





# Tachyon SMO (Source Mask Optimization)



By co-optimizing the illumination and reticle, SMO will calculate perfect light conditions and line shapes for an optimal process window.



# Introducing FlexRay™




FlexRay freeform illumination technology replaces a traditional illuminator and DOE\* combination with a programmable micro-mirror array. This allows it to render any SMO\*\* defined pupil shape in a matter of minutes.

\* diffractive optical element

\*\* source mask optimization




# Mask and freeform source co-optimization improve process window



# Tachyon SMO & FlexRay in Logic contact pattern:



Results in larger process window and lower mask complexity

ASML quadrupole illumination shape




74 nm Depth of Focus  
@ 5% EL

ASML freeform illumination shape




110 nm Depth of Focus  
@ 5% EL




# Reticle Specific Optimization combined with FlexRay illumination source adjustment

Compensating reticle bias errors while maintaining OPC validity




**Wafer CD**

Width = 44.1 nm  
Gap = 58.4 nm



+2 nm bias  
error yields  
6.5 nm  
gap error

Width = 44.1 nm  
Gap = 51.9 nm




Source  
adjustment

Width = 44.1 nm  
Gap = 58.4 nm




# ASML holistic lithography application flow to optimize the process window






# Improved production control



# Scanner tuning pre-sets and control loops for better production control




**Measurement**  
Mask design  
Monitor wafers  
Process wafers


**Tuning**  
Scanner tuning  
Scanner Setting Verification  
Process Control




# Better control for higher yield



# Better control for higher yield



# BaseLiner™ scanner stability




BaseLiner scanner stability is a complete scanner enhancement solution which maintains **overlay** and **focus** stability of TWINSCAN while increasing system availability.



# BaseLiner:

## Smaller variation in process window, increased availability



### System standard

System drift is countered by performing regular on-tool calibrations according to the ASML maintenance schedule to maintain the system within specified performance.

### Tighter control to support smaller process window

The process window can be maintained by performing more frequent calibrations, but this reduces availability/productivity and therefore decreases wafers-per-day.


### BaseLiner

BaseLiner eliminates additional calibrations and applies corrections more frequently. Measurements are done off-tool using monitor wafers. Tighter control with increased wafers-per-day



# BaseLiner: overlay stability improvement\*

Including strategy to maintain stability




\* Matched, full wafer on XT:1900i




# ASML holistic lithography flow for manufacturing

Faster ramp up and higher yield



# Holistic lithography provides a window to shrink



- Holistic lithography is the intelligent integration wafer lithography, computational lithography and process control
- Holistic lithography leverages increased and improved data integration to provide more control, better performance and higher yield


A series of thin, light blue curved lines that sweep from the bottom left towards the top right, creating a sense of motion and depth. They are more densely packed on the right side.

# **Eclipse<sup>TM</sup> Holistic Lithography packages**






# ASML makes Holistic Litho available via Eclipse



- Eclipse is a package of application- and node-specific products and services from our Holistic Lithography portfolio
- Eclipse packages provide chipmakers a window to shrink with cost reduction beyond traditional cost-per-layer

# ASML makes Holistic Litho available via Eclipse





**ASML**

